

# HELIX™

Micro-Rebar

Data Sheet

## Product: Helix 5-25

### Description:

The unique, twisted design of Helix allows for efficient tensile stress re-distribution within the concrete prior to concrete cracking. The result is a significant increase in the concrete's strain capacity and pre-crack properties. Unlike rebar and other forms of reinforcement, Helix provides proactive reinforcement which engages the concrete before large cracks form.

### Applications:

- Structural Walls
- Structural Floors
- Foundations
- Beams/Columns
- Shotcrete
- Paving
- Precast
- Rebar Replacement

### Approvals:

Uniform ES Evaluation Report 0279

[www.helixsteel.com/technical](http://www.helixsteel.com/technical)


[www.iapmoes.org](http://www.iapmoes.org)

### Meets Specifications:

ACI 318

ACI 360

ASTM A820-Type I



### Geometry:

Length: 25 mm (1.00 in)

Diameter: 0.50 mm (0.02 in)

25,307 fibers/kg (11,500 fibers/lb)

### Tensile Strength:

Tensile Strength: 246.5 ksi minimum  
(1700 Mpa minimum)

Material: High Carbon Steel Wire

### Coating:

Coating: Electroplated Zinc

For more information, visit [www.soconproducts.com](http://www.soconproducts.com)  
or call 540-537-4558.



Made in USA

# HELIX™

## Micro-Rebar

## Data Sheet

### Dosing Instructions:

Mixing should be done in accordance with ASTM C94 and the mixing instructions below. The dosages of Helix added to the mix should be noted on the batch documentation in accordance with Uniform Evaluation Service ER 279 Section 5.1.5, and verified using the procedure in ER 279 Appendix A.

### Mixing Instructions:

#### Ready Mix Plants (Dry) - TRUCK MIXER

To prevent Helix from clumping (small cluster of Helix), rigorously follow the procedures below: (1) Add a minimum of 20 gallons (75 liters) of the mix water into the drum. (2) With the drum at full charging speed, add the Helix into the truck drum. (3) Turn truck drum at charging speed for six minutes immediately prior to the addition of mix into truck. (4) Add the sand, aggregate and cement (or concrete) in the normal manner.

#### Ready Mix Wet (Central Mix)

- (1) For dosages below 15 lb/cyd (9kg/m<sup>3</sup>) follow dry procedures with 7 gallons (27 liters) of water in the drum.
- (2) For higher dosage please use the Site Batching instructions below.

#### Site Batching Into Mix Trucks (Loaded Truck at Construction Site)

- (1) Set the drum to charging speed. (2) Sift Helix through a 2" x 2" (50mm x 50mm) Mesh or use Helix Dosing Unit (contact Helix to order). The dosing unit breaks up clumps and ensures Helix goes into the truck at a controlled rate (about 1 box per minute). When Helix is added at this stage, it must enter the mixer clump free.
- (3) When adding Helix, it may collect on any residual concrete on the interior surfaces of the hopper. Push the Helix into the drum avoiding clumps. Adding a slippery lining, such as PVC sheeting, to the hopper may help avoid these buildups. (4) Mix at charging speed for 5 minutes (60 revolutions) after Helix is added.

#### Pan Mixer/Drum Mixer

- (1) Set the mixer to the proper speed. (2) Add Helix at a rate of 45-60 seconds per 45 lbs (20 kgs). (3) Helix should be added with the aggregates. (4) Mix at max speed for 5 minutes after Helix is added.

### Approvals:

Uniform ES Evaluation Report 0279

[www.helixsteel.com/technical](http://www.helixsteel.com/technical)


[www.iapmoes.org](http://www.iapmoes.org)

### Meets Specifications:

ACI 318

ACI 360

ASTM A820-Type I



For more information, visit [www.soconproducts.com](http://www.soconproducts.com)  
or call 540-537-4558.



Made in USA